


Reduced Viewing Angle Color Shift Defects via CVD Thickness Control


Problem

- Line-to-line defect rate variation
 - One OLED production line showed a higher VACS defect rate than others
- Inline vs cell-level inspection discrepancy
 - While inline light-on inspection showed stable color coordinates, cell-level light-on inspection revealed a high defect rate




Investigation

- Chamber-to-chamber defect rate variation
 - Identified **CVD chamber-to-chamber variation** in VACS defect rates
- Defect vs CVD thickness map
 - Compared **CVD thickness** maps across chambers and correlated them with defect patterns



[Defect map]




[CVD thickness map]

- Process sequence
 - CVD encapsulation occurs between inline and cell-level inspections

Hypothesis

- Optical path effect
 - **Encapsulation thickness** variation affects **optical performance**



Verification

- CVD thickness DOE
 - Confirmed **higher VACS defect rates** with **thicker encapsulation**
- Inline vs cell-level inspection consistency check
 - Restored inline–cell inspection consistency after CVD thickness control

Action

- CVD thickness window optimization
 - **Optimized CVD thickness window** with related teams to minimize optical impact while maintaining encapsulation performance
- Chamber-to-chamber CVD thickness alignment
 - Implemented **chamber-to-chamber thickness alignment** to reduce VACS defect variation